



# INSTALLATION MANUAL - VELAR 20 INGROUND

## Safety tips before installation

- \* Let always an expert/authorized technician make the installation
- \* Before you start please shut off the power to prevent electric shock
- \* Consider always leave some space to the heat sink of the LED light, it need to cool down after use
- \* Do not connect any LED light without its recommended driver
- \* Your individual product may vary from the design shown as following pictures
- \* Do not disassemble your product
- \* If any modification is made in the item or any wrong installation cause any damage to it, the warranty will be invalidated.




## STEP 1




1. Install the pre-recessed PVC box, keep the cable through the PVC box

## STEP 2



2. Connect the cable on the light with power cable ,pls leave some length for future maintainance


## STEP 3




3. Adjust the angle modulation knob to the angle you need, then push the light into the PVC box



## STEP 4



4. Tighten the screws on the cover ,finished.



## USE IP 68 Connectors



(Optional accessory)

